Product Information Bulletin

¹/₂" GEN 2 Check Valve Product Line

REV	DATE	DESCRIPTION	ORIGIN (issued by)	APPROVED
Rev 002	02-25-2020	Added Table for ½" POC Throttling Check Valves. Updated parts assembly	SD	
Rev 001	09-26-2016	100-092616-001	СҮ	

COMPANY PROPRIETARY INFORMATION

© 2014 - 2020 Proserv Gilmore Valve, LLC and/or its affiliates (Gilmore). All rights reserved. Proserv®, Gilmore™, Gilmore & Design (Stallion) and Gilmore, a Proserv Company™ are registered trademarks or trademarks of Gilmore. This Bulletin and the information contained herein is not to be, in whole or in part, reproduced or transmitted in any form by any means without the express permission of Gilmore. DISCLAIMER: Whilst Gilmore has carefully reviewed the contents of this Bulletin and believes the information to be correct, Gilmore does not assume any liability in connection with any use of or reliance upon this information and gives no representation or warranty, express or implied, in respect of the information or any products described herein. This Bulletin is intended for use by persons having suitable technical expertise and skill, at their own discretion and risk. Gilmore may change the information contained herein at any time without notice.

For more information: Call (800) 469-8786 <u>Gilmore@proserv.com</u>

Gilmore, A Proserv Company 1231 Lumpkin Road Houston, TX 77043



Product Information Bulletin

1/2" GEN 2 Check Valve Product Line



Gilmore announces the new ½ inch GEN 2 Pilot Operated Check Valve (POCV) product line for critical offshore and subsea applications. The ½ inch GEN 2 POCV has been redesigned with significant improvements.

Features and Benefits:

- Qualification exceeds API 16D requirements
 - Two separate endurance tests at 2500 cycles each
 - Hyperbaric Chamber test to 100 cycles at 15000 ft depth
- Nitronic 60 Poppet style check mechanism for improved guidance
- One-piece Nitronic 60 piston with Elgiloy springs
- 316 SS body
- Nitronic 60 End Caps
- Delrin 511P check valve seat
- HNBR O-rings with PEEK double back-up rings
- Ability to be field serviced without need for special tools
- Non-piloted Check Valve versions also available

Figure 1 and 2. PN 29001-1: 1/2" NPT Pilot Operated Check Valve, External Vent and Cross-section



Gilmore has exceeded API 16D requirements by qualifying the new 1/2" GEN 2 Check Valve design to multiple endurance qualification cycle tests to 2500 cycles, at a starting flow rate of 15 gpm at 5000 psi, with a 1% - 4% water glycol test fluid.



www.gilmore.com

As a result of the new Gilmore 1/2" Check Valve product line, please note that sales of all legacy 1/2" Check Valve part numbers listed below were discontinued on September 29th, 2017. The new Gilmore 1/2" Check Valves are now available for purchase as replacements for the legacy Check Valves.

Gilmore will continue to support discontinued legacy 1/2" Check Valves:

- Gilmore will continue providing repair kits, seal kits and conversion kits in support of discontinued 1/2" Check Valves for a minimum of 3 years. The Gilmore 1/2" Check Valves listed below are field repairable.
- Gilmore Aftermarket will continue to support discontinued legacy products with factory failure analysis and repair services for a minimum of 3 years.

Table 1. Legacy and I	New 1/2" GEN 2 Check	Valve Part Numbers:
-----------------------	----------------------	---------------------

ltem	Legacy Description	Legacy Valve PN	Legacy Repair Kit PN	New Valve Description	New Valve PN	New Repair Kit PN
1	Conversion Kit, Adapter Retainer, Valve, Check, Pilot Operated, External Vent,1/2" NPT	100710	NA	Valve, Check, Pilot Operated, External Vent,1/2" NPT	29001-1	29001-1 RK
2	Conversion Kit, Adapter Retainer, Valve, Check, Pilot Operated, External Vent, 1/2" SAE	131257	131283 RK	Valve, Check, Pilot Operated, External Vent,1/2" SAE	29001-3	29001-3 RK
3	Valve, Check, Pilot Operated, External Vent,1/2" NPT	22720-1	22720-1 RK	Valve, Check, Pilot Operated, External Vent,1/2" NPT	29001-1	29001-1 RK
4	Valve, Check, Pilot Operated, External Vent,1/2" NPT	22720-3	22720-3 RK	Valve, Check, Pilot Operated, External Vent,1/2" NPT	29001-1	29001-1 RK
5	Valve, Check, Pilot Operated, External Vent,1/2" NPT	22720-5	22720-5 RK	Valve, Check, Pilot Operated, External Vent,1/2" NPT	29001-1	29001-1 RK
6	Valve, Check, Pilot Operated, External Vent,1/2" SAE	22720-6	22720-6 RK	Valve, Check, Pilot Operated, External Vent,1/2" SAE	29001-3	29001-3 RK
7	Valve, Check, Pilot Operated, External Vent,1/2" SAE	22724	22724 RK	Valve, Check, Pilot Operated, External Vent,1/2" SAE	29001-3	29001-3 RK
8	Valve, Check, Pilot Operated, External Vent,1/2" NPT	22724-1	22724-1 RK	Valve, Check, Pilot Operated, External Vent,1/2" NPT	29001-1	29001-1 RK
9	Valve, Check, Pilot Operated, Internal Vent, 1/2" NPT	22440-1	22440-1 RK	Valve, Check, Pilot Operated, Internal Vent,1/2" NPT	29001-2	29001-2 RK
10	Valve, Check, Pilot Operated, Internal Vent, 1/2" NPT	22440-2	22440-2 RK	Valve, Check, Pilot Operated, Internal Vent,1/2" NPT	29001-2	29001-2 RK
11	Valve, Check, Pilot Operated, Internal Vent, 1/2" NPT	22440-3	22440-3 RK	Valve, Check, Pilot Operated, Internal Vent,1/2" NPT	29001-2	29001-2 RK
12	Valve, Check, Pilot Operated, External Vent,1/2" NPT	25108	25108 RK	Valve, Check, Pilot Operated, External Vent,1/2" NPT 2	29001-1	29001-1 RK
13	Valve, Check, Pilot Operated, External Vent,1/2" NPT	25108-1	25108-1 RK	Valve, Check, Pilot Operated, External Vent,1/2" NPT	29001-1	29001-1 RK



www.gilmore.com

ltem	Legacy Description	Legacy Valve PN	Legacy Repair Kit PN	New Valve Description	New Valve PN	New Repair Kit PN
14	Valve, Check, Non-Piloted, 1/2" SAE	New PN	New PN	Valve, Check, Non-Piloted, 1/2" SAE	29000-2	29000-2 RK
15	Valve, Check, Non-Piloted, 3/8" NPT	25105	25105 RK	Valve, Check, Non-Piloted, 1/2" NPT	29000-1	29000-1 RK
16	Valve, Check, Non-Piloted, 1/2" NPT	25125	25125 RK	Valve, Check, Non-Piloted, 1/2" NPT	29000-1	29000-1 RK

Gilmore has additionally released a throttling ½" GEN 2 POCV designed to handle 5000 psi full differential pressure.



Figure 3 and 4.* PN 29114: 1/2" NPT GEN 2 Piloted Throttling Check Valve and Cross-section



*The throttled seat cap within PN 29114 ensures POCV integrity while managing full 5000 psi pressure differential.

Table 2. Legacy GEN 2 Pilote	d Throttling Check	Valve Part Numbers
------------------------------	--------------------	--------------------

ltem	Legacy Description	Legacy Valve PN	Legacy Repair Kit PN	New Valve Description	New Valve PN	New Repair Kit PN
1	N/A	N/A	N/A	Valve, Check, Throttling, Piloted, ½" NPTF 5000 PSI, Internal Vent	29114	29114 RK
2	N/A	N/A	N/A	Valve, Check Throttling, Piloted ½" SAE, 5000 PSI, Internal Vent	29064	29064 RK




www.gilmore.com

Table 3. Legacy Check Valve Part Numbers

Item	Legacy Description	Legacy Valve PN	Legacy Repair Kit PN	New Valve Description	New Valve PN	New Repair Kit PN
1	Valve, Check, Pilot Operated, Internal Vent,1/2" BSPP	22440-4	22440-4 RK	N/A	N/A	N/A
2	Valve, Check, Pilot Operated, Captured Vent,1/2" NPT	22720-4	22720-4 RK	N/A	N/A	N/A
3	Valve, Check, Pilot Operated, External Vent,1/2" NPT	25109	25109 RK	N/A	N/A	N/A
4	Valve, Check, Non-Piloted, 1/2" BSPP	25125-1	25125-1 RK	N/A	N/A	N/A
5	Valve, Check, Air Dome, External Vent,1/2" NPT	25132	25132 RK	N/A	N/A	N/A
6	Valve, Check, Well Bore Assisted, ½ NPT	25158	25158 RK	N/A	N/A	N/A
7	Valve, Check, 3/8" NPT Pilot, External Vent,1/2" NPT	28350	28350 RK	N/A	N/A	N/A


Gilmore will continue supporting these legacy valves through repair kits, seal kits and aftermarket support for a minimum of 3 years.



Α

3

1




Α


2


BILL OF MATERIAL	S			
DESCRIPTION	MATERIAL	QTY	RK	SK
BODY, 1/2" NPT, VALVE, CHECK, 1/2"	A276 TP 316	1		
SEAT CAP	A276 UNS S21800 (NITRONIC 60)	1		
SEAT	DELRIN 511P	1	х	х
O-RING	HNBR	1	х	х
O-RING	HNBR	1	Х	х
SPRING, POPPET	ELGILOY	1	Х	
POPPET	A276 UNS S21800 (NITRONIC 60)	1	х	

1

В









Α


	BILL OF MATERIALS							
DE	SCRIPTION	MATERIAL	QTY	RK	SK			
BO VALV	DY, 1/2" SAE, 'E, CHECK, 1/2"	A276 TP 316	1					
	SEAT CAP	A276 UNS S21800 (NITRONIC 60)	1					
	SEAT	DELRIN 511P	1	х	x			
	O-RING	HNBR	1	х	x			
	O-RING	HNBR	1	х	х			
SPR	RING, POPPET	ELGILOY	1	х				
	POPPET	A276 UNS S21800 (NITRONIC 60)	1	х				

1

В








4


3

2

	1			
BILL OF MATERIALS				
DESCRIPTION	MATERIAL	QTY	RK	SK
BODY, VALVE, CHECK	A276 TP 316	1		
SEAT CAP	A276 UNS S21800 (NITRONIC 60)	1		
PILOT CAP	A276 UNS 21800 (NITRONIC 60)	1		
SPRING, POPPET	ELGILOY	1	х	
SEAT	DELRIN 511P	1	х	x
POPPET	A276 UNS S21800 (NITRONIC 60)	1	х	
PISTON	A276 UNS S21800 (NITRONIC 60)	1		
SPRING, COMPRESSION	ELGILOY	1	х	
BACKUP RING	PEEK	2	х	x
O-RING	HNBR	1	х	х
BACKUP RING	PEEK	2	х	х
O-RING	HNBR	2	х	х
O-RING	HNBR	1	х	х
O-RING	HNBR	1	Х	x

В





4

B


Α


3

2

	1						
OF MATERIALS							
RIPTION	MATERIAL	QTY	RK	SK			
DY	A276 TP 316	1					
САР	A276 UNS S21800 (NITRONIC 60)	1					
T, 1/4" NPT, HECK, 1/2"	A 276 UNS 21800 (NITRONIC 60)]					
POPPET	ELGILOY	1	Х				
AT	DELRIN 511P	1	Х	х			
PPET	A276 UNS S21800 (NITRONIC 60)	1	Х				
ĨON	A276 UNS S21800 (NITRONIC 60)	1					
OMPRESSION	ELGILOY	1	Х				
IP RING	PEEK	2	Х	Х			
ING	HNBR	1	Х	x			
IP RING	PEEK	2	Х	X			
ING	HNBR	2	Х	x			
ING	HNBR	1	Х	x			
ING	HNBR	1	Х	x			

B







2


	l			
BILL OF MATERIALS				
DESCRIPTION	MATERIAL	QTY	RK	SK
BODY, VALVE, CHECK	A276 TP 316	1		
SEAT CAP	A276 UNS S21800 (NITRONIC 60)	1		
PILOT CAP	A276 UNS 21800 (NITRONIC 60)	1		
SPRING, POPPET	ELGILOY	1	х	
SEAT	DELRIN 511P	1	х	х
POPPET	A276 UNS S21800 (NITRONIC 60)	1	х	
PISTON	A276 UNS S21800 (NITRONIC 60)	1		
SPRING, COMPRESSION	ELGILOY	1	х	
BACKUP RING	PEEK	2	х	х
O-RING	HNBR	1	Х	х
BACKUP RING	PEEK	2	х	х
O-RING	HNBR	2	Х	х
O-RING	HNBR	1	х	х
O-RING	HNBR	1	Х	х


В





	1						
BILL OF MATERIALS							
CRIPTION	MATERIAL	QTY	RK	SK			
BODY	A276 TP 316	1					
ATCAP	A276 UNS S21800 (NITRONIC 60)	1					
ΟΤ CAP	A276 UNS 21800 (NITRONIC 60)	1					
G, POPPET	ELGILOY	1	х				
SEAT	DELRIN 511P	1	х	х			
OPPET	A 276 UNS S21800 (NITRONIC 60)	1	х				
ISTON	A 276 UNS S21800 (NITRONIC 60)	1					
COMPRESSION	ELGILOY	1	х				
KUP RING	PEEK	2	х	x			
)-RING	HNBR	1	x	x			
KUP RING	PEEK	2	x	x			
)-RING	HNBR	2	x	x			
)-RING	HNBR	1	x	x			
)-RING	HNBR	1	. X	x			
3-32 UNC X .25" _ONG	Z-31-8/32-4-SS	1					





		•					
BILL OF MATERIALS							
DES	CRIPTION	MATERIAL	QTY	RK	SK		
	BODY	A276 TP 316	1				
SEAT CAP		A276 UNS S21800 (NITRONIC 60)	1				
PILOT CAP		A276 UNS 21800 (NITRONIC 60)	1				
SPRING, POPPET		ELGILOY	1	х			
SEAT		DELRIN 511P	1	х	х		
POPPET		A276 UNS S21800 (NITRONIC 60)	1	х			
PISTON		A276 UNS S21800 (NITRONIC 60)	1				
SPRING, COMPRESSION		ELGILOY	1	х			
BACKUP RING		PEEK	2	х	x		
O-RING		HNBR	1	х	x		
BACKUP RING		PEEK	2	х	x		
O-RING		HNBR	2	х	X		
O-RING		HNBR	1	х	x		
(D-RING	HNBR	1	х	x		
INSERT, #	8-32 UNC X .25" LONG	Z-31-8/32-4-SS	1				